Built to Move. Made to Last.

The Desky COILFLEX™ Ergonomic Office Chair adjusts with you, not against you. Its wave-spring suspension and 3D mesh backrest balance comfort, breathability, and posture support through every movement. With 4D armrests, multi-function tilt, and precise seat depth control, our COILFLEX keeps you aligned, focused, and in flow all day long.




4 Tilt Settings (22° Recline)



Adjustable Lumbar Support



Extended-Reach Headrest for Taller Users



CoilFlex Cushion System



DESKY

COILFLEX™ ERGONOMIC OFFICE CHAIR




ASSEMBLY INSTRUCTIONS & FEATURES

PARTS

A CHAIR BACK QTY 1 	**E** CHAIR BASE QTY 1 	**I** SPRING WASHER QTY 3 
B SEAT BASE QTY 1 	**F** CASTERS QTY 5 	**J** WASHER QTY 3 
C ARMRESTS QTY 2 (L+R) 	**G** M6 ALLEN KEY QTY 1 	**K** M8x30 SCREW QTY 4 
D GAS CYLINDER QTY 1 	**H** M8x25 SCREW QTY 3 	**L** DOUBLE BUTTON CONNECTOR QTY 2 


ASSEMBLY GUIDE

STEP 1




Insert the 5 casters into the chair base.

STEP 2




Insert the gas cylinder into the chair base, ensuring the thinner section faces away from the caster wheels.

STEP 3




Place the left and right armrests of the chair to the seat cushion mechanism respectively with a gasket L*1 and two screws K*2.


STEP 4



Position the seat cushion mechanism upside down. Align the backrest holes with the three holes on the mechanism and tighten using the three screws provided.




STEP 5



Insert the tip of the gas cylinder into the underside of the main body of the chair. Sit on the chair to firmly engage the cylinder.

HEIGHT ADJUSTMENT & TILT TENSION




❶ Seat Height Adjustment
Lift the lever beneath the seat to raise or lower the chair.

❷ Tilt Tension Adjustment
Turn the tension knob (usually located under the seat) to control how easily the chair reclines.

Turn clockwise for firmer resistance.
Turn counterclockwise for a looser, more relaxed tilt.

BACK TILT/ RECLINE




Backrest Recline Adjustment
Adjust the backrest to one of four recline positions to suit your comfort.

Total recline range: 22°

Lean back and engage your preferred position until it locks into place.

Choose a more upright angle for focused work, or a deeper recline for a more relaxed posture.

FORWARD/BACKWARD ARMREST




Armrest Depth Adjustment
Slide the armrests forward or backward to suit your seating position.

Total adjustment range: 80 mm

Position them so your elbows stay supported without restricting movement.

SIDE/ ROTATION ARMREST




Armrest Width & Angle Adjustment
Adjust the armrests side to side and rotate them to match your natural arm position.

Side-to-side adjustment range: 30 mm

Angle adjustment range: -20° to +25°

SEAT DEPTH




Seat Depth Adjustment
Adjust the seat depth to better support your legs and improve comfort.

6 position settings

Total adjustment range: 50 mm

Slide the seat forward or backward until there's a small gap between the back of your knees and the seat edge. This helps maintain good circulation and proper support.

ARMREST HEIGHT



Armrest Height Adjustment
Adjust the armrests up or down to support your arms comfortably.

7 height positions

Total adjustment range: 80 mm

Raise or lower the armrests until your elbows rest naturally at your sides, helping to reduce shoulder strain.


OPTIONAL HEADREST ASSEMBLY INSTRUCTIONS

PARTS

A HEADREST QTY 1 	**B** M6x16 SCREWS QTY 2 	**C** M6 ALLEN KEY QTY 1 


ASSEMBLY GUIDE

STEP 1




Remove the two rubber stoppers from the back frame.

STEP 2



Remove the chair headrest from its individual carton.

STEP 3



Use the two screws shown in the image to attach the headrest to the backrest.