
# DESKY® QUAD MONITOR ARM INSTALLATION


**PARTS**

| | | | | | | |
|---|---|---|---|---|---|---|
| **A** **CLAMP MOUNT** QTY1 | **B** **THROUGH DESK MOUNT** QTY1 | **C** **GROMMET MOUNT PLATE** QTY1 | **D** **CABLE CLIP** QTY1 | **E** **SCREW** QTY8 | **F** **SWIVEL KEY** QTY1 | **G** **TENSION KEY** QTY1 |
| **H** **TILT KEY** QTY1 | **I** **VESA BRACKET** QTY4 | **J** **SUPPORTING MOUNT** QTY1 | **K** **ARM MOUNT** QTY2 | **L** **ARM** QTY4 | | |


## INSTALLATION DESK CLAMP





## INSTALLATION THRU-DESK





## STEP 1





## STEP 2




## STEP 3





## STEP 4




# DESKY® QUAD MONITOR ARM ADJUSTMENT GUIDE


**STEP 1**




**STEP 2**




**STEP 3**




Try to make the above adjustments based on the monitor's weight in order to get the best free movement.

**STEP 4**

