
DESKY®

ADJUSTABLE MICROPHONE BOOM ARM INSTRUCTION MANUAL

PARTS


A **ARM MOUNT** QTY1



B **THROUGH DESK MOUNT** QTY1




C **LOCKING PLATE** QTY1




D **TIGHTENING CLIP** QTY1



E **MIC ARM** QTY1




STEP 1



Mounting the arm via the clamp (recommended).


STEP 2






If mounting through desk, remove the clamp using a Phillips head screwdriver.


STEP 3





If mounting through the desk drill a hole into your desktop using a 6-8mm drill bit. Insert part C and B into the base (A) and tighten using part D

STEP 4



Adjust the boom arm to suit your microphone using the 3/8” or 5/8” screw.