





DESKY


MINIMAL FILING CABINET
ASSEMBLY INSTRUCTIONS

INSTRUCTIONS DE MONTAGE POUR L'ARMOIRE DE CLASSEMENT MINIMALE

A Drawer Frame QTY 1 	**B** Top Front QTY 1 	**C** Bottom Front QTY 1 	**D** Drawer Handle QTY2 
E Inner Organizer QTY 1 	**F** File Bracket QTY 1 	**G** Lock With Key QTY 1 	**H** Unlocked Casters QTY 2 
I Lockable Casters QTY 2 	**J** Fixed Caster Wheel QTY 1 	**K** Screw Cover QTY 4 	**L** ST4.2X13 QTY 4 
		M ST4.2X13 QTY 2 	**N** M6x12 QTY 8 

STEP 1







STEP 2

If the drawer cannot be pulled out, push the protective cardboard to the left.


Si le tiroir ne peut pas être tiré, poussez le carton de protection vers la gauche.




STEP 3




STEP 4



STEP 5




STEP 6




Make sure the locking mechanism is oriented as shown in the illustration.

Assurez-vous que le mécanisme de verrouillage est orienté comme indiqué sur l'illustration.

STEP 7




STEP 8




Slide the drawer back in the cabinet.

Remettez le tiroir dans le meuble.


STEP 9



STEP 10




STEP 11




Turn the key to lock or unlock the cabinet. (It is recommended to lock the cabinet before moving it to prevent the drawers from sliding out and causing injury.


Tournez la clé pour verrouiller ou déverrouiller l'armoire. (Il est recommandé de verrouiller l'armoire avant de la déplacer afin d'éviter que les tiroirs ne glissent et ne provoquent des blessures.)

STEP 12



STEP 13





STEP 14

