

DESKY® SPOTLIGHT CORDLESS LAMP SAFETY & OPERATING INSTRUCTIONS

ASSEMBLY




ON/OFF

Brightness memory is maintained. Every time the lamp is switch on, the lighting brightness will be the same as the previous setting.




STEPLESS DIMMER

⚠ ONLY WORKS WHEN THE LIGHT IS ON




CCT STEPLESS ADJUSTMENT

⚠ ONLY WORKS WHEN THE LIGHT IS ON




To increase, turn clockwise.




To decrease, turn anti-clockwise.

CHARGING



⚠ WHEN CHARGING, LIGHT WILL BE ORANGE



⚠ WHEN FULLY CHARGED LIGHT WILL BE GREEN

