

DESKY® SIT STAND MOTION STOOL INSTRUCTION MANUAL

PARTS


A SEAT QTY1



B PLASTIC TUBE QTY1



C GAS LIFT QTY1




D BASE QTY1




STEP 1

Remove the black plastic cap from the tip of the cylinder **C**.




STEP 2

Insert the tapered end of the cylinder **C** into the base **D**.




STEP 3

Press firmly on the plastic tube **B** until it clicks into the seat **A**.




STEP 4


Slide the seat **A** + **B** onto the cylinder **C**. Once aligned, press firmly on the seat to engage the seat into the cylinder.



To raise/lower the seat, press any of the 2 buttons under the seat while sitting or pushing on the seat.



A wobble stool is designed to let you move freely. The stool can rock, tillt, and swivel 360 .



IMPORTANT!
Only sit on a wobble stool if both of your feet are planted firmly on the ground, and supporting your entire bodyweight.

